



## Delphi 3 Pin connector to Trailer 4 Pin Flat Connector

Thank you for purchasing XTC's **UNI-3PIN-TRAOUT** Plug & Play Trailer Power Adapter for Powering small trailer lights with a 4 terminal flat molded connector, it also includes License Plate Light or Whip Light power out.

1. Unplug OEM rear light harness.



Ranger-900 Center Rear over eng.



RZR-XP14 Drivers Side Rear Corner



Honda 1000 Remove either Tail Light

2. Plug the adapter into both OEM connectors, In and Out, on the Honda Remove either Tail light and install on Harness.

**WARNING! Keep power wire away from any hot or moving parts.**

**WARNING! Do not exceed the overall power out of the OEM Brake Light or Tail Light system, it is only for low wattage LED lights.**

3. Run the wire down to the trailer hitch.
4. Using the supplied cable tie's, secure the Harness to the car once again making sure that it is kept away from any hot or moving parts.

**For more details on installation go to [www.xtcinstall.com](http://www.xtcinstall.com)**

We can also be reached by email at [support@xtcmotorsports.net](mailto:support@xtcmotorsports.net)

To purchase Accessories please visit our web site at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)

**Copyright © 2016 XTC MOTORSPORTS LLC, all rights reserved.**

XTC Power Products  
A Division of XTC Motorsports LLC  
925 N McQueen RD. #101  
Gilbert AZ 85233  
480-558-8588  
[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)