



## Polaris General Power Adapter

Thank you for purchasing XTC's Plug & Play Power Adapter for License Plate or Whip light.

Please read the instructions fully and familiarize yourself with the components before starting the install.

**WARNING! Keep power wire away from any hot or moving parts.**



Unplug OEM light connector located under rear dump bed. Plug the adapter in.

Run the adapter power wires to the License Plate Light or Whip Light.

Strip 1/4" off the red and black wires

Attach the red power wire to the positive wire on the light and the black wire to the negative using the supplied heat shrink butt connectors.

Using a heat gun heat the butt connectors at both ends to seal the connections

Using the supplied cable tie's, secure the power wire to the car once again making sure that the wire is kept away from any hot or moving parts.

**For more details on installation go to [www.xtcinstall.com](http://www.xtcinstall.com) . We can also be reached by email at [support@xtcpowerproducts.com](mailto:support@xtcpowerproducts.com)**

**To purchase Accessories please visit our web site at [www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)**

**Copyright © 2017 XTC MOTORSPORTS LLC, all rights reserved**

XTC Power Products  
A Division of XTC Motorsports LLC  
925 N McQueen RD. #101  
Gilbert AZ 85233  
480-558-8588  
[www.xtcpowerproducts.com](http://www.xtcpowerproducts.com)