





2015 - 2016 RZR Power Adapter

Thank you for purchasing XTC Motorsports RZR Power Adapter for License Plate Light or Whip Light.

For more details on installation go to www.xtcinstall.com

Please read the instructions fully and familiarize yourself with the components before starting the install. Quick Install Guide.

Unplug OEM light connector located on drivers side rear corner near air intake line.



Plug the adapter into both OEM connectors as shown above.

WARNING! Keep power wire away from any hot or moving parts.

Run the adapter power wires to License Plate Light or Whip Light.

Strip 1/4" off the red and black wires

Attach the red power wire to the positive wire on the light and the black wire to the negative using the supplied heat shrink butt connectors.

Using a heat gun heat the butt connectors at both ends to seal the connections

Using the supplied cable tie's, secure the power wire to the car once again making sure that the wire is kept away from any hot or moving parts.

For more details on installation go to www.xtcinstall.com . We can also be reached by email at support@xtcpowerproducts.com

XTC Power Products
A Division of XTC Motorsports LLC
925 N McQueen RD. #101
Gilbert AZ 85233
480-558-8588
www.xtcpowerproducts.com